


DATA SHEET: ds-batrlam

REAR LIGHT BATTERY INSTALLATION

IMPORTANT INFORMATION

- Before using the bike, make sure the light is firmly secured to the bracket and functions properly
- This product is water-resistant and can be used in the rain, do not submerge in water
- If the light becomes dirty, clean with a soft cloth and mild detergent
- Aggressive solvents and detergents will damage the product
- Batteries should be disposed of in accordance with local regulations



FITTING THE BATTERIES

- Remove the two screws from the front of the light (fig. 1) with a suitable screwdriver and put them aside
- The front section can then be removed from the rear cover (fig. 2), the cover will remain attached to the bike
- Fit the two batteries into the the light as shown (fig. 3) with the batteries in the correct orientation (fig. 4)
- Take care not to damage the battery terminals when doing this
- Check that the light is working correctly by pressing the power button on the top of the light
- Refit the front section of the light onto the rear cover
- Install and tighten the two screws to fasten the two parts of the light together




Fig. 4

BATTERY ORIENTATION